

Single Phase / 60 Hz.

5. For supply wire ampacities and overcurrent protection, see unit rating plate.
6. Ensure that wires from the blower remain connected to the board thermostat terminals after making the field thermostat connections.
7. A heat pump thermostat with fossil fuel back-up heat capability is **REQUIRED** for this system.
8. For 208V operation, inducer motor low speed resistor must be bypassed. Removed RED wire from resistor block and connect to piggyback terminal on opposite side.

- 10066030**
12/14