

User's Information and Installation Instructions

*MQ Control Board Dipswitch Settings

Prior to installation of this replacement control board, adjust the dipswitches to match the table according to the input on your particular model. The settings must correspond to your unit or the furnace will not function properly.

INPUT	SWITCH NUMBER*		
	1	2	3
60000	OFF	OFF	OFF
80000	ON	OFF	OFF
100000	OFF	ON	OFF
120000	ON	ON	OFF

* SWITCH NUMBER 3 NEEDS TO BE OFF AT ALL TIMES.



7090000

Specifications & illustrations subject to change without notice or incurring obligations (07/15).
O'Fallon, MO, © Nortek Global HVAC LLC 2015. All Rights Reserved.

User's Information and Installation Instructions

*MQ Control Board Dipswitch Settings

Prior to installation of this replacement control board, adjust the dipswitches to match the table according to the input on your particular model. The settings must correspond to your unit or the furnace will not function properly.

INPUT	SWITCH NUMBER*		
	1	2	3
60000	OFF	OFF	OFF
80000	ON	OFF	OFF
100000	OFF	ON	OFF
120000	ON	ON	OFF

* SWITCH NUMBER 3 NEEDS TO BE OFF AT ALL TIMES.



7090000

Specifications & illustrations subject to change without notice or incurring obligations (07/15).
O'Fallon, MO, © Nortek Global HVAC LLC 2015. All Rights Reserved.