WIRING DIAGRAM

H5HK018S-01

18KW, 1-Stage, 480 VAC, 3-Phase Electric Heater Kit

NOTES:

- 1. If any of the original wire supplied with this unit must be replaced, it must be replaced with wiring material of the same gauge size and temperture rating.
- 2. The installation of this heater kit may require a change in the blower speed. See Installation Instructions for details.
- 3. Use copper conductors with minimum temperature rating of 60C for supply connections.

