


# WIRING DIAGRAM

## Air Handler for IQ Drive System



- NOTES:**
1. Not suitable for systems exceeding 120V to ground.
  2. If any internal wiring must be replaced, it must be replaced with 105°C wire of the same gauge.

**LEGEND:**

|              |       |
|--------------|-------|
| FIELD WIRING | ----  |
| LOW VOLTAGE  | ————  |
| HIGH VOLTAGE | ————— |



**710872A**  
(Replaces 7108720)