WIRING DIAGRAM H3HK005H-01C **240VAC** 5 KW, 2-Circuit, 1-Phase Electric Heater Kit CONTACTOR LIMIT **ELEMENT** 5 YELLOW • 8 9-PIN **HEATER PLUG** COMPRESSOR CONTACTOR NOTES: 0 0 1. Circuit breakers are not wired to heater kit by the factory, see **TERMINAL** Installation Instructions for wiring procedure. **BLOCK** 2. If any of the original wire supplied with this unit must **O**L1 101 be replaced, it must be replaced with wiring material of the same gauge size and temperature rating. The installation of this heater kit may require a change in the blower speed tap connection. See Installation **CIRCUIT** Instructions for details. **BREAKERS** 3. Use copper conductors with a minimum temperature rating of 60 C for supply connections. LEGEND: FIELD WIRING --**CIRCUIT B CIRCUIT A** 711441B LOW VOLTAGE (Replaces 711441A) HIGH VOLTAGE