

REPLACEMENT PARTS LIST

**MG2S DOWNFLOW
TWO STAGE CONDENSING GAS FURNACE
96+% AFUE**



**Front Return
with Coil Box**



**Top Return
with Coil Box**

MG2S REPLACEMENT PARTS LIST

| DESCRIPTION | 045F | 045T | 060F | 060T | 072F | 072T |
|---|----------|----------|----------|----------|----------|----------|
| BLOWER ASSEMBLY | 1022912R | 1022912R | 1022912R | 1022912R | 1022912R | 1022912R |
| BLOWER CONTROL BOARD | 624840R | 624840R | 624840R | 624840R | 624840R | 624840R |
| BLOWER DECK LIMIT SWITCH | 626602R | 626602R | 626602R | 626602R | 626602R | 626602R |
| BLOWER MOTOR | 622684R | 622684R | 622684R | 622684R | 622684R | 622684R |
| BLOWER MOTOR MOUNT KIT | 904951 | 904951 | 904951 | 904951 | 904951 | 904951 |
| BLOWER WHEEL | 667258R | 667258R | 667258R | 667258R | 667258R | 667258R |
| BURNER BOX ASSEMBLY | 922017 | 922017 | 922018 | 922018 | 1022918R | 1022918R |
| BURNER TUBE MANIFOLD | 664639R | 664639R | 664639R | 664639R | 664640R | 664640R |
| BURNER VIEW PORT (NOT SHOWN) | 632216R | 632216R | 632216R | 632216R | 632216R | 632216R |
| COIL DOOR ASSEMBLY (NOT SHOWN) | 903094 | 903094 | 903094 | 903094 | 903094 | 903094 |
| COMBUSTION AIR INLET PIPE | 664645R | 664645R | 664645R | 664645R | 664645R | 664645R |
| DOOR ASSEMBLY (LOUVERED) (BW MODELS) | 922094 | NA | 922094 | NA | 922094 | NA |
| DOOR ASSEMBLY (NON-LOUVERED) (BWT MODELS) | NA | 922095 | NA | 922095 | NA | 922095 |
| DOOR LATCH | 618107R | 618107R | 618107R | 618107R | 618107R | 618107R |
| DOOR LATCH FASTENER | 606317R | 606317R | 606317R | 606317R | 606317R | 606317R |
| DOOR SWITCH | 632337R | 632337R | 632337R | 632337R | 632337R | 632337R |
| DRAIN TEE | 618060R | 618060R | 618060R | 618060R | 618060R | 618060R |
| DRAIN TUBE (HARD "J") (NOT SHOWN) | 663706R | 663706R | 663706R | 663706R | 663706R | 663706R |
| DRAIN TUBE (SOFT, 23") (NOT SHOWN) | 664434R | 664434R | 664434R | 664434R | 664434R | 664434R |
| DRAIN TUBE (SOFT, 42") (NOT SHOWN) | 664278R | 664278R | 664278R | 664278R | 664278R | 664278R |
| FILTER (BWT MODELS) | NA | 669779R | NA | 669779R | NA | 669779R |
| FLAME SENSOR | 632396R | 632396R | 632396R | 632396R | 632396R | 632396R |
| FURNACE CONTROL BOARD | 624790R | 624790R | 624790R | 624790R | 624790R | 624790R |
| FUSE | 632261R | 632261R | 632261R | 632261R | 632261R | 632261R |
| GAS VALVE | 624787R | 624787R | 624787R | 624787R | 624787R | 624787R |
| HEAT EXCHANGER (NOT SHOWN) | 921597 | 921597 | 921597 | 921597 | 921598 | 921598 |
| HIGH TEMP HOSE (NOT SHOWN) | 263967R | 263967R | 263967R | 263967R | 263967R | 263967R |
| IGNITER | 1016290S | 1016290S | 1016290S | 1016290S | 1016290S | 1016290S |
| INDUCER LIMIT SWITCH | 626599R | 626599R | 626599R | 626599R | 626599R | 626599R |
| INDUCER MOTOR WITH ORIFICE | 1025335 | 1025335 | 1025335 | 1025335 | 1025335 | 1025335 |
| INDUCER ORIFICE (NOT SHOWN) | 670012R | 1023976R | 669749R | 669718R | 669719R | 1021493R |
| INLINE DRAIN ASSEMBLY | 664435R | 664435R | 664435R | 664435R | 664435R | 664435R |
| INSHOT BURNER | 661135R | 661135R | 661135R | 661135R | 661135R | 661135R |
| MAIN AIR LIMIT SWITCH | 600445R | 626617R | 626567R | 626617R | 626612R | 1018472R |
| ORIFICE (LP GAS) | 661078R | 661078R | 661082R | 661082R | 661079R | 661079R |
| ORIFICE (NATURAL GAS) | 661049R | 661049R | 661045R | 661045R | 661047R | 661047R |
| OUTLET HEADER BOX | 904802 | 904802 | 904802 | 904802 | 904802 | 904802 |
| PRESSURE SWITCH | 1023972R | 1023971R | 1023972R | 1023973R | 1023972R | 1023971R |
| ROLLOUT LIMIT SWITCH | 626608R | 626608R | 626608R | 626608R | 626608R | 626608R |
| SET OF WIRES (NOT SHOWN) | 1021547R | 1021547R | 1021547R | 1021547R | 1021547R | 1021547R |
| TRANSFORMER | 622341R | 622341R | 622341R | 622341R | 622341R | 622341R |
| VENT PIPE | 664644R | 664644R | 664644R | 664644R | 664644R | 664644R |

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

MG2S Gas Furnace Component Location



