


REPLACEMENT PARTS LIST

FLEX MATCH SYSTEM

FLOOR CEILING UNIT

GFH18(5.3)FMK4DH

ITEM #	COMPONENT
1	FIXED MOUNT
2	LOUVER CLAMP
3	GUIDE LOUVER
4	ROTATING SHAFT
5	FRONT CONNECTION BOARD
6	AIR LOUVER
7	BASE FRAME
8	INDUCED AIR PLATE SUBASSEMBLY
9	SUPPORTER
10	MID CLAPBOARD SUB-ASSY
11	FRONT VOLUTE CASING
12	REAR SIDE PLATE ASSY
13	CENTRIFUGAL FAN
14	SUPPORTER
15	AXILE BUSH
16	RIGHT SIDE PLATE SUB-ASSY
17	RIGHT COVER PLATE
18	INSTALLATION SUPPORTING FRAME
19	CONNECTION BOARD
20	JOINT SLACK
21	REAR CONNECTION BOARD
22	FAN MOTOR
23	BAR CLASP
24	BAR CLASP SUB-ASSY
25	REAR VOLUTE CASING
26	CABLE CROSS LOOP
27	FILTER
28	TEMPERATURE SENSOR
29	EVAPORATOR ASSY
30	PLATE BOARD OF WATER RELEASING FLUME
31	CONNECTION BOARD
32	WATER TRAY ASSY
33	FRONT GRILL SUB-ASSY
34	TOP COVER BOARD SUB-ASSY
35	SUPPORTER
36	LEFT SIDE PLATE SUB-ASSY
37	ROTATING SHAFT
38	ROTATING SHAFT
39	STEPPING MOTOR
40	ELECTRIC BOX ASSY
41	LEFT COVER PLATE
42	INSTALLATION SUPPORTING FRAME
43	DISPLAY BOARD
44	REMOTE CONTROLLER
45	DISPLAY BOARD
46	TERMINAL BOARD
47	CAPACITOR CBB61
48	ELECTRIC BOX COVER
49	TRANSFORMER
50	MAIN BOARD
51	ELECTRIC BOX
52	TEMPERATURE SENSOR



GFH18(5.3)FMK4DH

	PART DESCRIPTION	PART CODE	NORTEK PART NUMBER
1	Fixed Mount	26909426R	1044440
2	Louver Clamp	26112127	1044901
3	Guide Louver	10619403	1044442
4	Rotating Shaft (Spindle 3)	26909430	1044444
5	Front Connection Board	01349414P	1044443
6	Air Louver	10619404	1044446
7	Base Frame	26909448	1044900
8	Induced air plate subassembly	02229418	1044899
9	Supporter (Middle)	01805288	1044898
10	Mid Clapboard Sub-Assy	01249427	1044897
11	Front Volute Casing (Front 1/2 of Blower Housing)	26905205	1041743
12	Rear Side Plate Assy	01319440	1044896
13	Centrifugal Fan (Blower Wheel)	10425200	1041747
14	Supporter (Right)	01809417	1044895
15	Axile Bush	10542704	1028750
16	Right Side Plate Sub-Assy	01319429	1044449
17	Right Cover Plate	26909444	1044452
18	Installation Supporting Frame (Right Mounting Bracket)	01809402	1044450
19	Connection Board (Right Connecting Bracket)	02229406	1044453
20	Joint Slack (Coupling)	73018731	1041742
21	Rear Connection Board (Panel)	01349422	1044424
22	Fan Motor (Blower Motor)	15704111	1008294
23	Bar Clasp (Motor Clamp)	70818405	1044894
24	Bar Clasp Sub-Assy (Clamp Assy Motor)	70815201	1044893
25	Rear Volute Casing (Rear 1/2 of Blower Housing)	26905206	1041745
26	Cable Cross Loop	76514201	1044892
27	Filter (Refrigerant)	07216221	1032616
28	Temperature Sensor (Coil)	3900019822	1008298
29	Evaporator Assy	01029469	1044883
30	Plate Board of Water Releasing Flume	26909442	1044451
31	Connection Board	01344115	1044890
32	Water Tray Assy (Drain Pan)	01289404	1044423
33	Front Grill Sub-Assy	01579403	1044421
34	Top Cover Board Sub-Assy	01269409	1044422
35	Supporter (Left)	01809418	1044889
36	Left Side Plate Sub-Assy	0131942801	1044433
37	Rotating Shaft (Spindle 2)	26909412	1044435
38	Rotating Shaft (Spindle 1)	26909413	1044437
39	Stepping Motor (Louver Motor)	1521240206	1008293
40	Electric Box Assy	02404653	1044882
41	Left Cover Plate	26909443	1044887
42	Installation Supporting Frame (Left Mounting Bracket)	01809401	1044434
43	Display Board (Wired Controller)	300001060284	1028712
44	Remote Controller (WLRC3)	305100491	1007703
45	Display Board	30294220	1044936
46	Terminal Block	420111041	1032562
47	Capacitor CBB61	33010026	1044881
48	Electric Box Cover	01429420	1044885
49	Transformer	43110257	1032745
50	Main Board	30226350	1008296
51	Electric Box	01429419	1044884
52	Temperature Sensor (Ambient)	390001978G	1044134

