PARTNERS® choice
Universal HVAC Parts & Accessories

REPLACEMENT PARTS LIST

MG3P Series

Single Condensing Gas Furnaces

SINGLE STAGE CONDENSING GAS FURNACE
92% AFUE



MG3P-2
Upflow / Horizontal Furnace

92% AFUE SINGLE STAGE FURNACE

MG3P Upflow / Horizontal - Replacement Parts List.....2
MG3P Upflow / Horizontal - Component Location.....3

92% AFUE


MG3P UPFLOW / HORIZONTAL - REPLACEMENT PATYS LIST

DESCRIPTION	MG3P-054U1AAB*	MG3P-072U1AAC*	MG3P-090U1AAC*	MG3P-108U1AAD*
Blower Housing	297207R	—	—	—
Blower Housing (with Wheel)	—	1027002R	1027002R	1027002R
Blower Wheel	667258R	—	—	—
Blower Limit Switch	626611R	626611R	626611R	626611R
Blower Motor	104876902R	104876904R	104876905R	104876906R
Blower Motor Mount Kit	904951	904951	904907	904951
Blower Motor Choke	622340R	—	622340R	—
Burner Assembly	904927	904928	904929	904930
Burner Tube Manifold	664238R	664239R	664240R	664241R
Control Board NOTE: For units manufactured on or after 4/29/2025	1046397R	1046397R	1046397R	1046397R
Control Board Kit NOTE: For units manufactured on or before 4/28/2025	1050166	1050166	1050166	1050166
Door Set	904768	904769	904769	904770
Door Switch	632693R	632693R	632693R	632693R
Drain Tube (Hard, “J”) (Not Shown)	663706R	663706R	663706R	663706R
Drain Tube (Soft, “J” 30”) (Not Shown)	663707R	663707R	663707R	663707R
Drain Tube (Short Soft “J”) (Not Shown)	1049032R	1049032R	1049032R	1049032R
Filter	669784R	669785R	669785R	669786R
Finish Flange	664633R	664633R	664633R	664633R
Flame Sensor	632484R	632484R	632484R	632484R
Fuse	632261R	632261R	632261R	632261R
Gas Valve	1046626	1046626	1046626	1046626
Heat Exchanger	904869	904870	904871	904791
High Temperature Hose (Not Shown)	263967R	263967R	263967R	263967R
Ignitor (Nitride)	1046638S	1046638S	1046638S	1046638S
Inducer Limit Switch	626599R	626599R	626599R	626599R
Inducer Motor	1003441	1003441	1003441	1003441
Inducer Orifice	669712R	669715R	669717R	—
In-Line Drain Assembly	664435R	664435R	664435R	664435R
Inshot Burner	661134R	661134R	661134R	661134R
Main Air Limit Switch	626614R	1021533R	626613R	626614R
Orifice (Natural Gas)	661047R	661047R	661047R	661047R
Outlet Header Box	904802	904803	904803	904804
Pressure Switch (Condensate)	632491R	632491R	632622R	632491R
Pressure Switch (Inducer)	632520R	632493R	632493R	632493R
Roll-Out Limit Switch	626608R	626609R	626609R	626609R
Set of Wires (Not Shown)	104868716R	104868720R	104868720R	104868720R
Top Panel	2B3552R	2B3553R	2B3553R	2B3554R
Transformer	622341R	622341R	622341R	622341R
Tube (Soft, 6.5”) (Not Shown)	663727R	663727R	663727R	663727R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

FOR COMPONENT LOCATIONS, SEE PAGE 3

MG3P Upflow / Horizontal Component Location



Specifications & illustrations subject to change without notice or incurring obligations (09/25).
O'Fallon, MO, © Nordyne, LLC 2025. All Rights Reserved.

D315439A
(Replaces D3154390)